




TicTalk USB Driver Installation

Please follow these steps to install the USB drivers for the Enfora ® TicTalk.


Note: The following procedures and screen shots are specific to the Windows XP Operating System. The procedure to install the drivers on other Windows Operating Systems will be similar, but the screen shots may not be exactly the same.

First, you will need to download the TicTalk USB drivers from the <http://www.mytictalk.com> website.


1. Open Internet Explorer.
2. Navigate to <http://www.mytictalk.com>
3. Log into <http://www.mytictalk.com> using your TicTalk user id and password. You will see the following screen:




4. Under the **Photos** heading, click on the **Get USB Drivers** link. You will see the following screen:




5. Click on **Run**. You will see the following screen:




6. This screen is prompting the download of a file that was created by Enfora. It is safe to download this file. Click on **Run** to continue. You will see the following screen:




7. Click **Next** to continue. You will see the following screen:




8. Click on **Install**. You will see the following screen:



9. When the installation is complete, you will see the following screen:



7. Make sure the box marked **Run TicTalk USB Comport Drivers 1.1** is checked.
8. Click on **Finish**.
9. You will see the following screen:



10. Click on **Close**.

11. Connect your TicTalk to the USB port on your computer. You will see four dialog “balloons,” discovering the TicTalk and the Enfora USB information.



The final balloon will state that your TicTalk is ready to be used.



Congratulations! You have successfully installed the Enfora TicTalk USB drivers.